




WD 3 Battery Premium

The premium version of the battery-powered WD 3 Battery multi-purpose vacuum cleaner from the 36 V Battery Power battery platform is equipped with a 17 l stainless steel container. Battery available separately.



1 36 V Battery Power exchangeable battery

- Makes it possible to work without the need for a power supply and therefore achieve maximum freedom of movement.
- Real Time Technology with LCD battery display: remaining running time, remaining charging time and battery capacity.

2 Special cartridge filter

- For wet and dry vacuuming without filter replacement.

3 Practical blower function

- Where vacuuming is not possible, the practical blower function can be used.
- Effortless dirt removal, from a gravel bed, for example.

4 floor nozzle and suction hose

- For the best cleaning results – whether dry, wet, fine or coarse dirt.
- For maximum vacuuming convenience and flexibility.



WD 3 Battery Premium

- Battery-powered, battery and battery charger available as optional accessories
- Compatible with the Kärcher 36 V Battery Power system
- Practical blower function

Technical data

Order no.	1.629-950.0	
EAN code	4054278291864	
Rated input power	W	300
Container capacity	l	17
Container material	stainless steel	
Battery platform	Battery Power	
Battery voltage	V	36
Weight without accessories	kg	5.5
Dimensions (L × W × H)	mm	388 × 340 × 525

Equipment

Suction hose	m / mm	2 / 35	Accessory storage	■
Removable handle	■		Sturdy bumper	■
Suction tubes	piece(s) / m / mm	2 × 0.5 / 35 / plastic / -	Large castors (50 mm)	piece(s) 4
Wet and dry floor nozzle	clips			
Battery	-			
Battery charger	-			
Cartridge filter	standard			
Crevice nozzle	■			
Paper filter bag	piece(s)	1		
Blower function	■			
Parking position	■			

■ Included in the scope of supply.

WD 3 BATTERY PREMIUM 1.629-950.0

KÄRCHER



		Order no.	Quantity				Price	Description	
Filters									
Cartridge filter	1	6.414-552.0	1 piece(s)					Kärcher cartridge filter suitable for wet and dry use without filter replacement.	■
Paper filter bag	2	6.959-130.0	5 piece(s)					Two-ply paper filter bags with excellent filter capacity and high tear strength. Contains: 5 bags	□
Accessory kits									
Car interior cleaning kit	3	2.863-225.0	7 -part					Optimised car interior cleaning kit for comprehensive interior car cleaning: From dashboards to car seats, from upholstered surfaces to foot mats, from crevices and gaps to car boots.	□
Suction brush kit	4	2.863-221.0	2 -part					The suction brush kit enables thorough interior car cleaning of dashboards, foot mats, upholstered surfaces, etc., and is suitable for use on all materials. For all Home & Garden multi-purpose vacuum cleaners.	□
Household kit	5	2.863-002.0	2 -part					The household kit contains a switchable dry vacuum nozzle and an upholstery nozzle. This practical accessory kit is suitable for all Kärcher Home & Garden multi-purpose vacuum cleaners.	□
Vacuum kit for power tools	6	2.863-112.0	2 -part					Flexible suction hose (1 m) including adapter for connection to the exhaust air vent of power tools (e.g. jigsaws, grinders, drills, planes, etc.), for dirt-free DIY.	□
Nozzles									
Switchable wet and dry floor nozzle with integrated parking nib	7	2.863-000.0	1 piece(s)					Switchable wet and dry vacuum nozzle for perfect dirt intake. Easy adaptation to wet or dry dirt using foot switch. For all Kärcher Home & Garden multi-purpose vacuum cleaners.	□
Extra long crevice nozzle	8	2.863-223.0	1 piece(s)					Fully redesigned, extra long crevice nozzle. Ideal for hard-to-reach places inside the car (for example gaps and crevices). Suitable for all Kärcher Home & Garden multi-purpose vacs.	□
Car nozzle/suction nozzle for large areas	9	2.863-145.0	1 piece(s)					Handy car vacuuming tool for quick and easy cleaning - from the footwell to the boot.	□
Suction brush with hard bristles	10	2.863-146.0	1 piece(s)					Brush for thoroughly cleaning car upholstery and carpets. Hard brush easily removes dried dirt.	□
Suction brush with soft bristles	11	2.863-147.0	1 piece(s)					Brush with extra soft bristles for gentle cleaning of sensitive surfaces in the car, e.g. dashboards or centre consoles.	□
Special applications									
Ash filter/coarse dirt filter Basic	12	2.863-139.0						Coarse dirt/ash filter for cleaning fireplaces, tiled stoves, barbecues, sauna ovens, etc., as well as removing coarse dirt.	□
Ash filter/coarse dirt filter Premium	13	2.863-161.0						Premium coarse dirt/ash filter with fine filter suitable for cleaning fireplaces, tiled stoves, barbecues, sauna ovens, etc., as well as removing coarse dirt.	□
3.5 m suction hose extension	14	2.863-001.0						The 3.5 m long suction hose extension is suitable for all Kärcher multi-purpose vacuum cleaners from the Home & Garden area and ensures a larger working radius and greater free movement.	□
Extension suction tube	15	2.863-148.0						Practical extension suction tube for larger operating radius. The extension of the suction tube is recommended specially for applications in places that are difficult to access, e.g. high ceilings.	□

■ Included in the scope of supply. □ Available accessories.

WD 3 BATTERY PREMIUM 1.629-950.0



		Order no.	Quantity				Price	Description	
Drill dust catcher	16	2.863-234.0						The new accessory for our multi-purpose vacuum cleaners WD 2-6 allows safe and dust-free holes in conventional wall and ceiling surfaces. Drill dust is suctioned directly from the drill hole.	<input type="checkbox"/>

■ Included in the scope of supply. □ Available accessories.